




GITTOOLS



LED HEAD LAMP

GIHL

USER MANUAL

TABLE OF CONTENTS

Specifications	2
Safety Guidelines	3
Operation	4
Maintenance	4

SPECIFICATIONS

<i>LED Type</i>	SMD LED
<i>Battery</i>	2x AAA
<i>Maximum Lumens</i>	180lm
<i>Maximum Illumination Time</i>	7 Hours
<i>Function</i>	LED 100% LED 30% Strobe Off
<i>Light Range</i>	20m
<i>Weight</i>	45g
<i>Protection Class</i>	IPX5

Note

Thank you for the purchase of this GI TOOLS product. This manual is for your reference only. Due to the continuous improvement of the GI TOOLS products, changes may be made at any time without obligation or notice.

SAFETY GUIDELINES

Service

- **Have your tools and machinery serviced by your local distributor with genuine GI TOOLS replacement parts.** This will ensure that the safety of the power tool or machine is maintained.



WARNING

The warnings and precautions discussed in this manual cannot cover all possible conditions and situations that may occur. It must be understood by the operator that common sense and caution are factors which cannot be built into this product, but must be supplied by the operator.

Always Use Common Sense

- It is not possible to cover every conceivable situation you can face. Always exercise care and use your common sense. If you get into a situation where you feel unsafe, stop and seek expert advice. Contact your dealer, service agent, or an experienced user. Do not attempt any task you feel unsure of!

Worklight Specific Safety

- Do not look directly at the illuminated LED lights, or shine the LED in the eyes of other people or animals.
- This device utilises a battery that can be ruptured, ignited and cause serious injury if handled improperly. Adhere to the following safety rules:
- DO NOT place the battery and head lamp in fire or high temperature.
- DO NOT tamper with the battery wiring.
- DO NOT puncture or damage the battery.
- DO NOT use a battery that appears damaged or ruptured in any way.
- DO NOT immerse the battery or head lamp in water or other liquids.
- DO NOT alter or modify the battery in any way.
- DO NOT attempt changing the battery in any manner other than that prescribed in this manual.
- DO NOT dispose of the battery in fire or water, they may leak or rupture.
- DO NOT disassemble, crush, puncture, or otherwise damage the battery. This can result in leakage or rupture.
- Dispose of your batteries safely as per your local council rules. Alternatively you can bring them back to your local ToolShed and we can safely recycle them for you.

OPERATION

Headlamp Operation

Use the power button to cycle through the headlamps lighting modes.

- Press once: Turns the light on at full brightness (100% output).
- Press again: Reduces the light to low brightness (approximately 30% output).
- Press a third time: Turns the light off.
- Quickly double-press the button: Activates the strobe function. The light will flash rapidly for signalling or emergency use.
- To exit the strobe function, press the power button again.

NOTE: A normal second press selects the low-brightness mode, while two rapid presses activate the strobe function.

MAINTENANCE

- Before cleaning or performing any maintenance, you must ensure the tool is switched off.
- Ventilation openings and switch levers must be kept clean. DO NOT attempt to clean by inserting pointed objects through openings.
- Do not use harsh chemicals or solvents when cleaning this tool.
- If you discover any damaged or broken parts, consult your nearest GI Tools distributor for replacements and advise.
- Before cleaning the head lamp, switch it off. Allow the head lamp to cool down sufficiently.
- Clean with a dry or slightly moist, clean, lint free cloth, and a mild detergent if required.
- Do not use cleaners that contain abrasives or solvents.
- Check the LED head light for damage before each use.
- Clean any dirt or debris from the housing or the lens immediately, since it could cause overheating or dim the light brightness.