



## PEDESTAL FAN 750MM



TSVE8



[www.thetoolshed.co.nz](http://www.thetoolshed.co.nz)



## OPERATION MANUAL

### PRODUCT DETAILS

PRODUCT

Pedestal Fan 750mm

MODEL NO.

TSVE8

DISTRIBUTED BY



#### **NOTE:**

This manual is only for your reference. Due to the continuous improvement of the ToolShed products, changes may be made at any time without obligation or notice.

#### **WARRANTY**

This product may be covered under the ToolShed warranty. For more information see our Terms & Conditions at [www.thetoolshed.co.nz](http://www.thetoolshed.co.nz)



---

OPERATION MANUAL

---

CONTENTS:

Product Details ..... 2

Specifications..... 4

Safety Warnings ..... 4

Assembly Instructions ..... 5

Use / Maintenance ..... 6

**SPECIFICATIONS**

Drive Type / Application	Direct-Drive – Pedestal
Airflow	290m3 / Min Max
Speeds	3
Blade Diameter	750mm
Blade Type	Cast Alloy
Power (Volt/Hz/Watts)	230V / 50Hz / 280W



**WARNING** READ ALL SAFETY WARNINGS AND ALL INSTRUCTIONS. Failure to follow instructions and warnings could lead to serious injury, electric shock, or fire. Save ALL warnings and instructions for future reference.

**ELECTRICAL SAFETY**

- **Do NOT use the power tool in raining conditions or wet areas where the power tool could get wet.** Water in the power tool can lead to electric shock.
- **Only use the power tool when the plug correctly matches the power outlet.** Modifying plugs greatly increases the risk of electric shock.
- **Keep the power cord away from anything that could damage it such as sharp edges, moving parts or heat.** A damaged power cord increases the risk of electric shock.
- **Only operate outdoors with the use of an outdoor extension lead.** Not all extension leads are suited to outdoor use and using one which is not can greatly increase the risk of electric shock.

**SPECIFIC SAFETY INSTRUCTIONS**

- DO NOT use the fan outdoors
- NEVER use the fan unless it is fully assembled
- DO NOT push finger or any object through the grilles and do not touch the fan blade during use. Be extra cautious when children and infants are around during use.
- Take care that objects are not sucked into the fan during operation.
- Unplug from wall outlet before servicing.

## ASSEMBLY INSTRUCTIONS


### BASE ASSEMBLY

1. Locate Hardware Bag "A" to assemble base. (Figure 1)
2. Fit the column on the centre of base.
3. Insert (4) M6X12mm hex bolts through the flange of the column and base.
4. Tilt base and secure one hex bolt at a time by first putting on a split-lock washer and washer then nut (M6).




DO NOT FULLY TIGHTEN AT THIS TIME.

Repeat above procedure with remaining bolts.

5. Go back and fully tighten each nut so that the flange of the column is securely assembled to the base.





### Decoration Cover



### DECORATION COVER ASSEMBLY

Locate the decoration cover to assemble into the column. (Figure 2)

1. Loosen the screw which is pointed at by the arrow and take off the neck.
2. Put the decoration cover into the column.
3. Tighten up the screw.
4. Turn the knob and the height of the inner column can be adjusted accordingly.




### MOTOR ASSEMBLY

Locate the whole set for the motor to assemble into the column. (Figure 3)

1. The tongue on the connection can match the groove on the inner column for easy assembly.
2. Insert the connection into the top of the inner column.
3. Tighten up two screws on the back (Figure 4)

### REAR GRILL ASSEMBLY

Unscrew these 4 screws on the motor, and then assemble the rear grill.



### FAN BLADE ASSEMBLY

1. Insert the fan blade on the shaft of the motor and let the lateral screw face the flat surface on the shaft.
2. Fully tighten up the lateral screw of the fan blade. Be careful, the fan blade should be assembled in the correct direction. (Figure 7)




Figure 6

### FRONT GRILL ASSEMBLY

1. Assemble the front grill in the grill ring and then fit with the matched rear grill.
2. Close all the locks on the front grill to finish the assembly. (Figure 9)




Figure 7




Figure 8




Figure 9

### USE AND MAINTENANCE

1. Before cleaning, ensure the fan is unplugged and the fan blades have stopped spinning.
2. Disassemble the grill and wash with a soft cloth and soapy water.
3. DO NOT get water in or around the motor.