ASSEMBLY INSTRUCTION

Step 1



Step 2



Ax1	Bx1	Cx4	Dx4	Ex1