

TECHNICAL DATA SHEET

Dy-Mark (Aust) Pty Ltd PO Box 1556 • Toowong 4066 • Phone: 1300 396 275 • Fax: 1300 360 440
www.dymark.com.au



Dy-Mark PROTECH® Isopropyl Alcohol



Dy-Mark PROTECH Isopropyl Alcohol is a high purity cleaning solvent. It dries quickly and leaves no residue. It is non-corrosive, non-conducting and contains no lubricants. It is excellent for cleaning oil, dirt, dust, fingerprints, flux and polar soils from precision electronics and electrical equipment.

DIRECTIONS FOR USE

Recommended Uses

Printer heads, thermal printers, circuit boards, telephones, Plus keyboards, switches, controls, connectors, contacts, relays, motors, circuit breakers, terminals, tape heads, sensors and other uses.

(Plus show smaller version of pictures from front of can)

Directions

De-activate and isolate equipment before use. Do not use on energised equipment. Shake can well. Shake can occasionally during use. Spray can in **UPRIGHT** position only. Spray onto surface from a distance of 15-20cms. Use extension tube for hard to reach areas. Repeat application if necessary. Allow product to dry completely and thoroughly. **Vent the system before restoring power.** When finished spraying, actuator can be set in lock position to prevent accidental actuation.

It is advisable to test on a sample before use. Maybe harmful to certain sensitive plastics. For all precision instruments, check with manufacturer.

(Plus 2 pictures of Actuator in 2 spray positions) 1. Normal spray 2. Hard to reach areas

TECHNICAL DATA

Size:	275g Aerosol
Colour:	Clear
Consistency:	Liquid
Propellant:	Hydrocarbon
Warning:	UN1950 AEROSOL

SAFETY INFORMATION

Eliminate all potential sources of ignition in or near the workplace. Do not smoke and ensure adequate ventilation during use. Avoid breathing dust, vapour or spray mist. Wear protective gloves and eye protection during mixing and use. Avoid repeated or prolonged skin contact.

FIRST AID

KEEP OUT OF REACH OF CHILDREN

If swallowed: Do not induce vomiting.

Eye contact: In case of contact with eyes, rinse immediately with plenty of water. Seek medical advice from your doctor or Poisons Information Centre (**Australia: 13 11 26; New Zealand: 0800 764 766**).

Note: the information provided within this Technical Data Sheet is intended as a guide only. The performance of this product will depend on many factors outside the control of Dy-Mark; including surface type and environmental conditions. Refer to Material Safety Data Sheet for more information.