



## Chromate 100mg/L

CODE: STR-034-100

### DATA SHEET

#### Instructions for use

1. Immerse an indicator strip in the test solution for 1 second.
2. Shake off excess solution.
3. Wait 20 seconds.
4. Compare the colour produced on the strip against the colour chart.

#### Measuring range

0 - 3 - 10 - 30 - 100mg/L

#### Application

Chromate test strips detect aqueous chromate ions within wastewater streams in the electroplating industry. Chromates are extremely toxic and carcinogenic.

#### Shelf Life

2 years from manufacturing date.

## Contents

100 strips

## Dimensions

Strip dimension: 83mm x 5mm

## Notes

Keep any unused strips in the original container. Do not store where they are liable to be exposed to acid or alkaline gases or vapours. Store in a cool dry place.

