



Peroxide 100mg/L

CODE: STR-161-100

DATA SHEET

Instructions for use

1. Immerse an indicator strip in the test solution for 2 seconds.
2. Shake off excess solution.
3. Wait 30 seconds.
4. Compare the colour produced on the strip against the colour chart.

Measuring range

0 - 1 - 3 - 10 - 30 - 100mg/L

Application

Peroxide test strips detect residual peroxides, for example, in drinking water, pools, and hot tubs where Hydrogen Peroxide may be used as a disinfectant.

Shelf Life

2 years from manufacturing date when stored between 2 - 8°C.

Contents

100 strips

Dimensions

Strip dimension: 83mm x 5mm

Notes

Keep any unused strips in the original container. Do not store where they are liable to be exposed to acid or alkaline gases or vapours. Store in a cool dry place.

