



lab_{co} QAC 400mg/L

CODE: STR-171-400

DATA SHEET

Instructions for use

1. Immerse an indicator strip in the test solution for 1 second.
2. Shake off excess solution.
3. Hold horizontally for 10 seconds.
4. Compare the colour produced on the strip against the colour chart.

Measuring range

0 - 100 - 200 - 300 - 400mg/L

Application

QAC test strips detect the level of quaternary ammonium compounds in cleaning solutions. This enables the user to verify the required level of disinfectant is present before cleaning commences.

Shelf Life

3 years from manufacturing date.

Contents

100 strips

Dimensions

Strip dimension: 83mm x 5mm

Notes

Keep any unused strips in the original container. Do not store where they are liable to be exposed to acid or alkaline gases or vapours. Store in a cool dry place.

