

Activator® 4-relay output remote control- RSR03



Applications – Alarm & Access Control

This 4-relay output remote control can be used to operate Arm (away/ stay), Disarm, Panic and Garage Door for any alarm control panels, as a typical alarm installation. It also can be used to operate other electric devices such as electric strike and auto gate.

Default Setting

- All 4-relay outputs are defaulted to momentary operation.
- Two remotes have been learned to the receiver as part of kit.

Learn a Remote

1. Press and hold the program button PROG on the receiver for one second; LED on.
2. Press any button on the remote to learn (Note: The remote must be learned in by pressing button 1 to keep Default Setting). LED flashes 3 times and stays on for 4 seconds then off.

Delete all Remotes

Press and hold program button PROG on the receiver for 5 seconds till LED turns off. LED flashes 10 times.

Delete an Individual Remote

1. Recall the remote which had been learned into the receiver first before the last remote
2. Press and hold program button PROG on the receiver for 1 second; LED on.
3. Press Button 1 and Button 2 simultaneously; LED flashes 5 times and off, successfully deleting the last remote.

Program Relay Operation

Relay 3 & 4 can be programmed to momentary, latching or delay operation. When learning a remote into the receiver, pressing different buttons will result in different output operations

Relay 1	Relay 2	Relay 3	Relay 4
Momentary	Momentary	Momentary	Momentary
Momentary	Momentary	Momentary	Momentary
Momentary	Momentary	Momentary	Momentary
Momentary	Momentary	Momentary	Momentary
Momentary	Momentary	Momentary	Momentary
Momentary	Momentary	Momentary	Momentary
Momentary	Momentary	Momentary	Momentary

Warning

The remote contains a lithium coin battery. It is hazardous and is to be kept away from children (whether the battery is new or old). Please dispose of used batteries immediately. The battery can cause severe or fatal injuries in 2 hours or less if it is swallowed or placed inside any part of the body. Please seek medical attention immediately if it is suspected the battery has been swallowed or placed inside any part of the body.