


Programmatic Control on Tektronix USB Real Time Spectrum Analyzers

APPLICATION NOTE



2020

2030

Introduction

Using the latest in commercial interfaces and available computing power, the Tektronix RSA 300/500/600 USB real time spectrum analyzers separate signal acquisition from measurement, dramatically lowering the cost of instrument hardware. The series is also well suited for applications that need automatic measurements or remote control.

The programs can be created in the host PC, and the remote control implemented over an Ethernet connection through a small, low-cost PC, such as Intel NUC, paired with each RSA. Tektronix provides programmatic control using several different interfaces to support your applications. This application note will explain the programmatic interfaces and environments available for Tektronix RSA USB spectrum analyzers and provide recommendations and examples for your applications.




Figure 1 Multiple point remote control with Tektronix RSA507A spectrum analyzers with Intel NUC mini PCs

Block Diagrams of Tektronix USB Spectrum Analyzers

Within the spectrum analyzer hardware, an RF downconverter translates the input RF signal to the IF (intermediate frequency) with 40 MHz bandwidth. The IF is sampled at 112 Msps (Msamples/sec) by a 14-bit ADC (analog to digital converter), producing a stream of IF samples that are formatted and transferred by a USB 3.0 connection to the PC. Other brick inputs allow synchronization of the internal reference oscillator to an external reference source or enable the use of external trigger or GPS timing pulses.




Figure 2 Simplified hardware structure of Tektronix RSA306B

The PC platform (a workstation, laptop, or tablet) provides control to the spectrum analyzer hardware via USB 3.0 connection. In the PC, the IF samples are received by the USB Host HW and Driver, which pass them to the RSA306 API SW DLL. The API (application programming interface) provides public access to four different formats of the signal data including:

- processed IQ data blocks.
- complete DPX bitmap images.
- demodulated audio.
- raw ADC samples.

As well, the API provides the control interface to the hardware. Applications such as SignalVu-PC use the API to configure the hardware, retrieve DPX image blocks and IQ samples for analysis, and support continuous storage of raw sample data to file. User applications can also access the API for customized developments.




Figure 3 Simplified software architecture of Tektronix RSA306B

The Two Programmatic Control Methods

There are two methods to control Tektronix USB spectrum analyzers programmatically. Both methods can be implemented in different programming platforms, such as C, C++, C#, Matlab, Python, LabVIEW, and others.

Method 1, SignalVu-PC PI: Traditional benchtop spectrum analyzers, like Tektronix RSA5000 and RSA6000, have always had a PI (programming interface) to allow remote control of instruments, remote data gathering, and automated testing. The PI implemented SCPI (Standard Commands for Programmable Instruments) commands that could be sent to the controlling software to perform operations such as instrument setup, start acquisitions, retrieve spectra and calculated data, etc. With the RSA300/500/600 USB controlled spectrum analyzers, the application software SignalVu-PC maintained the same interface as the spectrum analysis software controlling the Tektronix benchtop spectrum analyzers. Consequently, the same PI is still in place for these USB spectrum analyzers for programmatic control. PI SCPI commands can be sent to the SignalVu-PC code that controls the USB spectrum analyzer via either the TekVISA VXI-11 Server (virtual GPIB) or the TekVISA Socket Server (Windows sockets). The RSA API is the new piece of code written to interface the hardware to the data ports of the SignalVu-PC software.

Method 2, RSA API: Sometimes users don't need many high-level, complicated signal analysis in SignalVu-PC, but they want to implement basic code fast or do further deep processing based on the acquired data. In this case, the RSA API provides a better option to meet those needs. SignalVu-PC doesn't need to be run, and the user can access the low-level API for fast data processing.




Figure 4 The two programming Interface of Tektronix RSAs

Depending on your applications, the PI and API methods have pros and cons. Here are our recommendations on which method is preferred based on different programming purposes.

Programming Purposes	SignalVu-PC PI	RSA API
Making RF measurements that are included in SignalVu-PC, particularly when analysis results are returned on screen.	✓	
Testing RF standards supported by SignalVu-PC where measurement limits are included in the software, many of which are pass/fail.	✓	
Collecting streaming data for later analysis.		✓
Capture data fast and efficiently		✓
Creating complicated higher-level applications by yourselves		✓
Streaming data with narrow bandwidth		✓

Table 1 When to use PI and when to use API

Control by SignalVu-PC PI

To program the RSAs through the SCPI commands with SignalVu-PC software, these are the four steps to follow:

- 1 •Download and install the SignalVu-PC with TekVISA
- 2 •Launch SignalVu-PC with a connect the USB RSA
- 3 •Install the drivers for your selected programming platform when necessary*
- 4 •Start to make your program

* You need to install the LabVIEW driver to use NI LabVIEW. No additional drivers are needed for platforms like C, C++, C#, Matlab, and Python.

The PI of SignalVu-PC uses SCPI and IEEE 488.2 Common Commands. Figure 5 shows the command parts as described in the Command Syntax subsection.




Figure 5: SCPI Command Parts

Each command works in a particular measurement view(s). Table 2 lists all available measurement displays supported by the SignalVu-PC software, the measurement view it's in, and if it requires an installed option.

Measurement sets	Options
General signal viewing	Free
Analog modulation	Free
General purpose digital modulation	Option SVM
RF measurements	Free
OFDM analysis	Option SVO
Audio analysis	Option SVA
Bluetooth analysis	Option SV27
LTE Analysis	Option SV28
P25 analysis	Option SV26
Pulsed RF	Option SVP
WLAN analysis	Options SV23, SV24, SV25
EMC pre-compliance and troubleshooting	Option EMCVu
Tracking generator	Option SV60 and 04 (HW)

Table 2 The PI measurements supported in SignalVu-PC

Control by RSA API

There are three steps to program the RSAs directly through the API driver:

- 1 •Download and install the RSA API driver
- 2 •Install the drivers for your selected programming platform when necessary**
- 3 •Start to make your program

** For RSA API programming, we provide a Matlab driver for Matlab and IVI driver for LabVIEW. The API itself was implemented by C++ so it's compatible with C/C++. Controlling RSAs with Python is straightforward without needing any additional drivers.

Two benefits of the RSA API are that you don't need to keep SignalVu-PC running continuously or install any VISA drivers.

The API driver of RSA provides a simple, fast way to program the instrument. Therefore, the available measurements of the API are limited compared to SignalVu-PC. However, it still makes available the most common actions programmers need:

Functionalities	Options
Instrument Setup (Alignment, Configure, Device, GNSS, Trigger, power, Time)	No options and free
DPX	
Spectrum	
IQ block	
IQ streaming	
IF streaming	
Playback	
Tracking generator	

Table 3 The available API function sets

One benefit of using API is streaming the IQ and IF data down to 200 kHz bandwidth, which is useful for reducing the total size of captured streaming data. This feature will save more space if your interested signals are narrow band.

Application Examples

PI Example 1: LabVIEW based Bluetooth production test

Test engineers face many obstacles when integrating a spectrum analyzer into a test rack. Not only do these engineers have power and size limitations, but there are also questions about selecting the right spectrum analyzer for the tests required. Common measurements include channel power, occupied BW, frequency, modulation, and spurious.

LabVIEW is software already widely used with hardware instruments in production tests of RF devices and systems. Tektronix RSAs provide LabVIEW drivers for PI and API programming. This PI example shows the usage of LabVIEW and RSA306B to build a Bluetooth transmitter test system for production tests. The programming method uses VISA with the PI driver to call the Bluetooth analysis results of SignalVu-PC.

Figure 6 shows the Bluetooth analysis user interface in SignalVu-PC, which allows users access to analysis windows such as spectrum, time overview, constellation, summary table, and frequency deviation.




Figure 6 The Bluetooth basic rate analysis in SignalVu-PC

Figure 7 is the front panel in LabVIEW. The design of the front panel is flexible and could be simplified to only show the most straightforward test results like pass/fail for technicians in the factory.




Figure 7 LabVIEW front panel to call the Bluetooth test results

PI Example 2: C++ based system integration development

System integration is a process of bringing together subsystems into one system for specialized tasks. Systems integration provides testing of instruments, racks, and subsystems, as well as design and development of specialized sensors and science instruments.

C++ is an object-oriented programming language that includes classes, inheritance, polymorphism, data abstraction, and encapsulation. C++ is a highly portable language and often the language of choice for app development to control test instruments such as spectrum analyzers. Software development using VISA is intended for instrument I/O and C, C++, or Visual Basic programmers familiar with the Windows environment. Tektronix spectrum analyzers provide flexible ways for system integrators to develop programs using C and C++.

This PI example shows a government-use spectrum monitoring and jamming system developed by Tektronix system integration partner ZTHY Communication Technology. The system was designed based on the Tektronix RSA306B and SignalVu-PC. C++ was used as the software system integration tool.

Figure 8 is the hardware structure of the system.




Figure 8: Hardware structure of the monitoring system

Figure 9 is the user interface compiled by C++ and based on SignalVu-PC commands. The test system includes complex features like DPX, FM demodulation, and power/frequency/phase vs. time, making PI through VISA preferred rather than API.




Figure 9 The software user interface of ZTHY DG - M6

API Example 1: C++ based 3rd party spectrum monitoring software

Programming using the Tektronix RSA300/500/600 series API benefits users in capturing data fast and efficiently when high-level complicated signal analysis in SignalVu-PC isn't needed. This API example shows a 3rd party software developed by Decodio for wideband signal acquisition, channelization, demodulation, and streaming.

The Decodio Spectrum Monitoring System is a full-featured software solution for signal analysis and professional mobile radio (PMR) communication decoding. Based on hardware instruments including Tektronix RSA306B and RSA503A/507A, the system covers all aspects of spectrum monitoring, from distributed signal acquisition to content analysis.





Figure 10 Decodio Spectrum Monitoring System

API Example 2: MATLAB based RF and communication education system

MATLAB is one of the most widely used simulation tools in education. Many professors use MATLAB to help students better understand and apply concepts to a wide range of engineering, science, and mathematics applications, including wireless communication, signal processing, microwave theory, and others.

Tektronix SignalVu-PC is supported by the MATLAB Instrument Control Toolbox. This integration allows professors and students access to the complex analysis tools in SignalVu-PC.

Programming with PI or API also helps in cases where professors or graduate students want to develop their own programs for classes or projects on communication or RF designs.

This API example shows MATLAB Simulink being used for an RF transceiver design. Tektronix RSA306 develops the Simulink system through the RSA API driver.




Figure 11 MATLAB controlling Tektronix RSA306 through API driver

Summary

Tektronix RSA 300/500/600 series USB real time spectrum analyzers provide users two flexible programming ways to control instrument remotely. Using SCPI commands through VISA to control SignalVu-PC is great to get the results of complicated The API method bypasses SignalVu-PC software, and gives users a better option to capture data fast and efficiently for later analysis.

For sample code and examples of controlling Tektronix USB spectrum analyzers, visit:

<https://github.com/tektronixofficial/?q=RSA>

For a complete listing of available spectrum analyzers from Tektronix, visit Tek.com.

Contact Information:

Australia 1 800 709 465
Austria 00800 2255 4835
Balkans, Israel, South Africa and other ISE Countries +41 52 675 3777
Belgium 00800 2255 4835
Brazil +55 (11) 3759 7627
Canada 1 800 833 9200
Central East Europe / Baltics +41 52 675 3777
Central Europe / Greece +41 52 675 3777
Denmark +45 80 88 1401
Finland +41 52 675 3777
France 00800 2255 4835
Germany 00800 2255 4835
Hong Kong 400 820 5835
India 000 800 650 1835
Indonesia 007 803 601 5249
Italy 00800 2255 4835
Japan 81 (3) 6714 3010
Luxembourg +41 52 675 3777
Malaysia 1 800 22 55835
Mexico, Central / South America and Caribbean 52 (55) 56 04 50 90
Middle East, Asia, and North Africa +41 52 675 3777
The Netherlands 00800 2255 4835
New Zealand 0800 800 238
Norway 800 16098
People's Republic of China 400 820 5835
Philippines 1 800 1601 0077
Poland +41 52 675 3777
Portugal 80 08 12370
Republic of Korea +82 2 6917 5000
Russia / CIS +7 (495) 6647564
Singapore 800 6011 473
South Africa +41 52 675 3777
Spain 00800 2255 4835
Sweden 00800 2255 4835
Switzerland 00800 2255 4835
Taiwan 886 (2) 2656 6688
Thailand 1 800 011 931
United Kingdom / Ireland 00800 2255 4835
USA 1 800 833 9200
Vietnam 12060128

For More Information:



Vicom Australia

1064 Centre Rd
Oakleigh South Vic 3167
Australia
1300 360 251
info@vicom.com.au
www.vicom.com.au

Vicom New Zealand

Grd Floor, 60 Grafton Road
Auckland 1010
New Zealand
+64 9 379 4596
info@vicom.co.nz
www.vicom.co.nz

Find more valuable resources at TEK.COM

