

Hygiene Stands & Stations

Material Specifications

- Stand: #304 Stainless Steel Frame and Face, ABS Plastic Base Cover
- Sanitiser Dispenser: #304 Stainless Steel, ABS Top and Base

Finishes

- Designer Black ML_STAND_BLK
- White Powder Coat ML_STAND_WHT
- Designer Black ML_HYGSTATION_BLK_BLK
- Designer Black & Stainless Steel ML_HYGSTATION_BLK_SS
- White & Stainless Steel ML_HYGSTATION_WHT_SS
- White & Designer Black ML_HYGSTATION_WHT_BLK

Dimensions

400mmW x 1440mmH

Installation Guidelines

 May be subject to Australian Building Code Regulations for height and location fixing and may be subject to placement as per architectural drawings. In all cases, this is the responsibility of the installer.

For Stand Only:

- 1. Attach pole to base plate
- 2. Insert bolt under base plate and tighten firmly
- Attach Face Plate to pole and tighten using the screws provided

Hygiene Station Mounting:

- 1. Attach pole to base plate
- 2. Insert bolt under base plate and tighten firmly
- **3.** Attach Face Plate to pole and tighten using the screws provided
- **4.** To mount the dispenser, insert screw and washer through the dispenser backing plate and face plate.
- **5.** To secure, add washer and M3 nut on other side of face plate and tighten (apply step 4 & 5 to other three mounting holes).


Operation

 Sanitiser spray is automatically dispensed when hands are placed in/under sensor zone.

Consumable Advice

- Please ensure to clean the sanitiser container properly before each re-fill as deposits of old consumable will lead to malfunction and jamming.
- A 75% ethanol alcohol-based disinfectant spray with a PH level between 4.3~8.3 and a Viscosity Range of 1cps should be used in this dispenser to ensure the dispenser performs at an optimal level. * Any liquids not within these ranges may cause the unit to operate at a sub-optimal level, fail or damage the unit and could void the Metlam Australia product warranty.





The photographs and line drawings of the products presented above are representational only.

Metlam Australia Pty Ltd reserves the right to, and from time to time, make changes and improvements in design and dimensions

Metlam Australia Pty Ltd T: +61 3 5420 8800 F: +61 3 5420 8899 E: sales@metlam.com.au www.metlam.com.au

Information Sheet



Features

Stand

- Strong & Sturdy #304 Stainless Steel Frame
- Rounded Edge Design

Sanitiser Dispenser Unit

- Touchless Automatic Operation Sanitiser Dispenser
- 800ml Removable Reservoir
- Liquid Level Indicator
- LED Operation
- Vandal resistant security lock (key provided)
- Dispensing Volume: 0.8 1.1ml (0.027 0.037 fl oz)
- Powered by four AA Batteries (not included) provides approx. 16,000 cycles/one-year usage

The technical recommendations contained in this document are necessarily of a general nature and should not be relied on for specific applications without first securing competent advice. Whilst Metlam Australia Pty Ltd has taken all reasonable steps to ensure the information contained herein is accurate and current, it does not warrant the accuracy or completeness of the information and does not accept liability for errors or omissions. Any Commercial product should only be installed by a competent tradesperson and serviced/maintained by knowledgeable janitorial staff or competent people. Metlam Australia accepts no responsibility for any damage to product, walls or fixtures due to incorrect installation or maintenance of any of their products.

The photographs and line drawings of the products presented above are representational only.

Metlam Australia Pty Ltd reserves the right to, and from time to time, make changes and improvements in design and dimensions.

Metlam Australia Pty Ltd T: +61 3 5420 8800 F: +61 3 5420 8899 E: sales@metlam.com.au www.metlam.com.au