







Ammonia 6mg/L

DATA SHEET

Instructions for use

- 1. Fill vessel with sample.
- 2. Immerse strip in sample and move strip up and down for 30 seconds.
- 3. Leave strip in sample for 30 seconds.
- $4.\ \mbox{Remove}$ and compare the colour produced on the strip against the colour chart.

Measuring range

0 - 0.5 - 1.0 - 3.0 - 6.0mg/L

Application

Ammonia test strips detect ammonia in water samples. This is particularly important in aquariums where ammonia is extremely toxic and damaging to aquatic life.

Shelf Life

2 years from manufacturing date.

Contents

25 strips 1x test vial

ab.

Dimensions

Strip dimension: 83mm x 5mm

Notes

Keep any unused strips in the original container. Do not store where they are liable to be exposed to acid or alkaline gases or vapours. Store in a cool dry place.