





# Nitrite 25mg/L

# **DATA SHEET**

#### Instructions for use

- 1. Immerse an indicator strip in the test solution for 2 seconds.
- 2. Shake off excess solution.
- 3. Wait 45 seconds.
- $4. \ \mbox{Compare}$  the colour produced on the strip against the colour chart.

## **Measuring range**

0 - 0.5 - 1 - 5 - 10 - 25mg/L

#### **Application**

Nitrite test strips detect residual and build-up of nitrite, for example, in drinking water, waste water or aquariums.

#### **Shelf Life**

2 years from manufacturing date.

#### Contents

100 strips

#### **Dimensions**

Strip dimension: 83mm x 5mm

## Notes

Keep any unused strips in the original container. Do not store where they are liable to be exposed to acid or alkaline gases or vapours. Store in a cool dry place.

E.&O.E.