

Nibbio+ Quick guide

Wireless indoor reed-switch opening and shock detector

Installation guide





Fix the support to the wall using the screws provided or temporarily with the adhesive kit included in the package







Pull out the battery tab on the back of the detector.






Fix the detector on the bracket.






- Make sure you have aligned the detector in the right direction with the magnet before attaching it.
- On one side there is a small protrusion at the height of the LED which indicates the presence of the internal reed where it must be placed alongside the magnet.

Adhesive application





Configuration Nibbio via app D'AVINCI



Open the D'AVINCI app where the first system has been previously created.



Before scanning the QR code on the sensor Press the Add Device button. Type the requested data.



Press the sensor icon that has been added to enter the sensor status. Select the gear icon on the top right to program the device.



