

WARRANTY

Your Supreme Hand Dryer is fully guaranteed against defective materials and faulty workmanship for a period of 36 months from date of sale, subject to it being installed and maintained in accordance with the manufacturers instructions.

SPL Limited warrants that should any part of the dryer fail within one year of installation that part will be replaced or repaired free of charge. Mileage and travelling time outside metropolitan areas by tradesperson or accredited service agents is payable by the customer. Alternatively, the Dryer may be returned to SPL Limited or its accredited service agents for repair under warranty when the cost of removal, re-installation and cartage will be payable by the customer. This warranty does not cover the damage resulting from non-operation of the hand dryer, the use of non- authorised parts, failure due to accident, misuse, abuse or failure to follow installation and maintenance instructions or consequential damage to any other goods, furnishings or property. This warranty does not displace any statutory warranty in relation to the dryer but any liability of SPL Limited under any statutory warranty will be limited to a replacement or repair of the dryer or payment of the cost of such replacement or repair at the option of SPL Limited.

For all warranty enquiries on this product contact:

SPL

SPL Limited
PO Box 437, Cambridge 3450
New Zealand

Phone +64 7 823 5790
Fax + 62 7 823 5792
Email: office@splwashrooms.co.nz
www.splwashrooms.co.nz



The logo for Supreme hand dryers features a stylized blue wave icon to the left of the word "supreme" in a bold, lowercase, sans-serif font. Below "supreme" is the phrase "hand dryers" in a smaller, lowercase, sans-serif font.

JET DRY EXECUTIVE II High Efficiency Hand Dryer



Congratulations on choosing
Supreme Hand Dryers

For best results simply follow these instructions.

Phone: +64 7 823 5790

General Notes

Instructions must be followed carefully when installing the Jet Dry Executive II.

Do not use the dryer for any purpose other than drying hands.

All electrical work should be carried out by a qualified person in accordance with all local regulations.

General Specifications

Motor	- 30,000 RPM, 2 Speed Brushless Electronic Motor
Rating	- 230 - 240V AC IP33
Frequency	- 50/60 HZ
Max Airflow	- 155m/sec
Switching	- Infrared Self Adjusting
Cover	- ABS/Polycarbonate, Antimicrobial Infused
Dimensions	- 330W x 660H x 230D mm
Weight	- 9kg
Standards	- Complies with New Zealand and Australian Standards
Colours	- Platinum and Pearl

Planning

We suggest that one hand dryer be installed for every two hand basins. When positioning dryers, take note of traffic flows in the washroom, also be aware of obstructing doors, cabinets etc.

Safety Precautions & Standard Compliance


The Supreme Jet Dry Executive II complies with the relevant AUS/NZ Electrical Standards & Electromagnetic interference.

Caution

- The dryer is not intended for use by young children or infirm persons without supervision
- Young children should be supervised to ensure that they do not play with appliance
- Do not insert objects into the drying chamber
- Do not obstruct the air outlets in any way
- Do service the dryer at regular intervals. The HEPA filter should be replaced every 6 months or sooner in high use areas
- The dryer should only be maintained, repaired or removed by a qualified person

Unpacking


- 1) Remove all packaging material. Recycling is recommended where possible.
- 2) Carefully remove the dryer from the shipping carton taking care not to drop the appliance.
- 3) Inspect the dryer for damage, locate and retain the mounting bracket, cleaning brush and mounting template before disposal of packaging.



Installation

(Refer to Mounting Template for Fig 1, 4 & 5)

- 1) Using the mounting template supplied mark the position of the three mount bracket holes (fig 1) and the lower security fixing (fig 4) & (fig 5) **Note:** Recommended height for disabled installation if required
- 2) Before drilling holes for mounting, check for any hidden utility services
- 3) Mounting should be via suitable fasteners for the substance, nogging is preferred
- 4) The electrical supply should be supplied with a switch or breaker with a contact separation of at least 3mm in all poles
- 5) Mount dryer on the mounting bracket and fit the lower security screw located behind the water tray (Fig 5)
- 6) Set power switch to "On" and select speed control High/Low - High speed is recommended (see below)



Maintenance

1. All surfaces should be cleaned daily with a soft cloth or non-caustic cleaner.
2. The water container should be emptied and washed daily to avoid a slip hazard.
3. Weekly, clean the water pipe with brush provided.
4. The inlet filter screen and HEPA filter should be replaced every 6 months or after 25,000 operations.

WARNING

Your warranty could be void if filters are not replaced as recommended.

L.E.D Display

- Stand By - All lights off
Operation - Outer ring of LED1 rotate
Filter Change - LED2 will turn on after 25,000 operations. When filter has been replaced the LED2 will stay on for 5 seconds and then flash 3 times—counter reset
Water Tray - LED 3 Water container is full. Empty and flush container before refitting



Height recommendations

Recommended height from floor to mounting bracket

Female and Male Washrooms	910mm
Disabled Person's	760mm